

YOU WILL NEED

40mm jolt head galvanised nails

Drill with 10mm drill bit

Offcuts of wood and plywood (we used 22cm wide planks and 6mm plywood)

Hammer

Paintbrush

Pencil

Potting mix

Resene Waterborne Woodsman tinted to Resene Earthsong

Sandpaper

Saw

Set square

Good-quality potting mix

Three favourite herbs (we used mint, basil and parsley)

TOP TIPS

In a similar way, a series of stackable box planters could also be used to grow strawberries, small salad vegetables or even potted colour.





the paint the professionals use

For more on paints phone 0800 RESENE (0800 737 363) or visit your Resene ColorShop or **www.resene.co.nz**



STEP 1Measure and mark the wood into twelve 150mm pieces.



STEP 4
Assemble the pieces of wood, as shown, to form three rectangular boxes. Fix at each corner with 40mm nails.



STEP 7

Fix the plywood bases to the boxes with 40mm nails, as shown, and drill drainage holes in the base of each box.



STEP 2
Use the set square (or back of the saw) to mark perpendicular cutting lines across the wood, as shown.



STEP 5

Place one of the boxes on the piece of plywood and trace around the bottom to mark out the base.



STEP 8
Apply two coats of Resene
Waterborne Woodsman to the
wooden boxes, allowing two
hours for each coat to dry.



STEP 3
Using the pencil lines as a guide, cut the wood into twelve equal pieces, and sand any rough edges.



STEP 6
Using the pencil lines as a guide, cut the base out of the plywood and sand any rough edges. Repeat for the other two boxes.



STEP 9
Fill each box with
potting mix and plant a herb
in each one. Stack the three
boxes to form a triangle.