





## MATERIALS

You will need: • Ornate frame – mine, which I found on Trade Me measures 37cm x 24cm • Wood glue

- 1m 40mm x 10mm pine strip Plastic containers (mine were 90mm x 60mm x 60mm deep) Sandpaper
- Nails/hole punch 20mm screws
- Chain for hanging
   Skil saw/hand saw
   Resene Quick Dry Primer, test pots
   Brushes

Cutting list: Seed holder: 2 x 200mm, 2 x 75mm, 1 x 55mm Cost: \$35 excluding paint

- Renovate the frame as required.
  Remove any glass, images and backing board. Here, I needed to re-glue the joins and repair some of the ornate edges with filler. Clamp and allow to dry.
- 2 Create a seed holder by measuring the plastic containers and building a frame. Glue and nail together, hole punch the nail heads, fill and allow to dry. Sand well.
- Undercoat both pieces with Resene Quick Dry Primer. Top coat in your chosen colour once dry.
- Cut the chain to length and attach.
  Angle screw the seed holder to the back of the frame. Fill the containers with seed or seed and water.