





## MATERIALS

You will need • 1.3m – 40mm x 10mm pine or similar • Collected dry branches, similar dimensions, some with Y-angles • Corner clamp • Wood glue • Filler • Sandpaper • 2 x saw tooth picture hangers or similar • Drop saw / hand saw • Resene Quick Dry Primer and test pots, paintbrushes Cost: \$10 excluding paint

Cut the timber into 2 x 400mm and 2 x 200mm lengths. Join the pieces together using the wood glue and the corner clamp. Allow to dry. Fill any gaps with filler. Once dry, sand well. Undercoat with Resene Quick Dry Primer and apply two top coats with your chosen test pot – I used Lazy River.

2 Cut the branches into manageable lengths. Play with the layout adding plain lengths between the Y–shaped ones. Shorten the hook ends as required. Cut all to 200mm.

3 Insert the cut lengths carefully and glue into position. I used some timber underneath the frame to keep the wood aligned with the front edge while the glue dried. Sand off excess glue.

For additional support glue, two triangular corner brackets to the back top of the frame. Attach hanging device either here or on the frame edge.

PHOTOS: ROSE HUGHES