

hat better way to enjoy a languid summer afternoon than with a book and cushions in the garden – or even better, on a swing bed, made with a wooden pallet and freshly covered squab and cushions.

## You will need

machine, pins and scissors.

For the pallet \* sturdy wooden pallet \* saw, nails, hammer, drill with 15mm drill bit \* Resene Lumbersider waterborne low sheen (approximately 1 litre) in a Resene paint colour of your choice

– I used Resene Timekeeper \* Resene Wood Primer or Resene TimberLock (optional).

For the wooden cross bar \* 2 lengths of 50mm x 100mm timber (when crossed, these need to match diagonal width of pallet)
\* 150mm galvanised bolt, washer and nut \* 4 large nails \* 3 lengths of 10mm rope (total length dependent on height of trees)
For the mattress \* sponge mattress \* cushions \* fabric, sewing

**Step 1:** Measure your mattress against the pallet and mark where you need to cut the pallet down. Cut it to shape and reinforce any edges with the wood offcuts. Drill a 15mm hole through each corner of the pallet.

Step 2: Paint the pallet with Resene Lumbersider in a colour of your choice. Resene Lumbersider is a tough, washable outdoor paint. For maximum durability in exposed conditions, undercoat first using Resene Wood Primer or Resene TimberLock. Or you can choose to paint directly onto the wood. Allow to fully dry.

Step 3: Drill holes at the ends and centre of your 2 timber lengths. Connect the timber lengths together with the bolt, washer and nut to make cross bars.

Starting at the top of the pallet, thread one end of a rope though the drilled corner of the pallet. Tie the end of the rope off with a secure double knot.

Measure 3 metres from the top of the pallet and tie a slip knot (insert a large nail into the middle of the knot to stop it from slipping). This knot stops the cross bar from sliding down. Thread the remaining length of rope through one end of the cross bar and back through the hole in the top of the opposite end of that same length of timber. Allow for enough slack in the rope for it to be raised ½ metre above the crossbar. Tie another slip knot (using a nail as before) in the rope under the cross bar. Thread the rope down though the corresponding diagonal corner of the pallet.

Repeat process with other cross bar. Ensure all 4 lengths of rope are the same between the pallet and the cross bar. Also ensure the 2 lengths of rope above the crossbar are the same length. Tie a double knot under the base of each pallet corner so that the pallet hangs straight. Adjust these as necessary once you have hung the pallet.

Take third length of rope and tie two lengths above crossbar together. Throw the other end of this rope over a sturdy branch, hoist pallet up and secure third rope firmly. Adjust as necessary. **Step 4:** Cover your mattress and scatter cushions in a fabric of your choice. I used a fabulous selection of cotton prints from the Liberty range, available at The Fabric Store.

Step 5: Assemble your garden pallet bed and enjoy! g



The painted garden
Adding a few selected
painted items is a clever
way to add all-year-round
colour to your garden.
The smokey tone of
Resene Timekeeper in
Lumbersider adds a deep
shade of blue that
complements the various
greens of your garden
without ever being jarring.





Resene
the paint the professionals use

For more paint, colour ideas and inspiration, visit your Resene ColorShop or resene.co.nz



Sarah is a contributing editor for Good and author of Reclaim That: Upcycling your Home with Style.

@reclaim\_that

sarahheeringa.com

82 good 8