CREATE YOUR OWN:

Stained chair

with MARK RAVNER

It's easy to transform a plain wicker chair into something special with Resene Waterborne Colorwood natural wood stain.

YOU WILL NEED:

- Resene Waterborne Colorwood natural wood stain tinted to Resene Rosewood
- gloss waterborne urethane varnish
- · Clean lint-free cloth
- Latex rubber gloves
- Paintbrushes
- Wicker chair





Step one

brush apply one coat of Resene Waterborne Colorwood stain to the woven edge of the chair, as shown. Take care to get the wood stain right in to the gaps in the weave.

Using a large artists'



Step two

Stain the back of the chair, starting at the top edge and working down. Leave for up to 15 minutes, before wiping off excess stain with a soft cloth (make sure you wear latex gloves when you do this).



Step three

Continue to work your way down the arms of the chair, again. wiping off the excess Resene Waterborne Colorwood stain as you go.



Step four

Apply one coat of Resene Waterborne Colorwood stain to the legs and bamboo binding around the base of the chair, again leaving for up to 15 minutes before wiping off excess.



Tips

For a paler look, try using Resene Waterborne Colorwood tinted to Resene Rock Salt or Resene Egg White

To get the look Mark painted the background wall with Resene Zylone Sheen tinted to Resene Sand and the skirting board with Resene Enamacryl tinted to Resene Alabaster.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website



Step five

Work your way around the sides and back of the chair, as shown, continuing to wipe off the excess stain as you go.



Step six

Turn the chair over and repeat the process underneath.



Step seven

Check for any areas you may have missed and touch these up with a small amount of Resene Waterborne Colorwood stain, wiping off any excess.



Step eight

Leave for 48 hours to dry, and then apply 3-4 coats of Resene Aquaclear varnish, allowing two hours drying time between coats.

Call 0800 RESENE (737 363) visit www.resene.co.nz or email advice@resene.co.nz



the paint the professionals use