Resene

Mini sandpit



★★ Difficulty level ★easy ★★moderate ★★★challenging

Toys and Games with Mark Rayner – 39

You will need:

- 90mm decking nails
- 150mm x 40mm timber (approx 700mm)
- Electric saw
- Fence capping (approx 1.9m)
- Hammer
- Hand saw
- Paintbrush

- Pencil
- Resene Lustacryl tinted to Resene Tomorrow
- Resene Quick Dry
- Sandpaper
- Tape measure
- Tongue and groove landscaping timber (approx 2.6m)



Step one

Measure, mark and cut the tongue and groove landscaping timber into two 700mm lengths and two 600mm lengths.



Step two

Assemble to form a rectangular frame, as shown, fixing at each corner with 90mm decking nails.



Step three

Measure, mark and cut the piece of 150mm x 40mm timber to fit along one edge to form a ledge seat, as shown, and fix into position with 90mm decking nails.



Step four

Measure, mark and cut three lengths of fence capping to fit around the top edges of the sandpit.



Step five

Using a hand saw, cut a little of the 'groove' from the back corners, as shown, to neatly accommodate the fence capping.



Step six

Fit the pieces of fence capping into position, fixing with 90mm decking nails. Smooth any rough edges on the sandpit using sandpaper.



Step seven

Apply one coat of Resene Quick Dry to the sandpit and allow to dry.



Step eight

Apply two coats of Resene Lustacryl tinted to Resene Tomorrow to the sandpit, allowing two hours for each coat to dry.





To get the look:
Mark painted the
background wall with
Resene AquaShield
tinted to Resene Dutch
White.



Other ideas:
For a vibrant orange
effect paint the sandpit
with Resene Lustacryl
tinted to Resene Hi Jinx.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.

