

all decked out

Jazz up a tired deck and improve your seating arrangements in time for the barbecue season.

You will need:

- Resene Moss & Mould Killer
- Resene Woodsman penetrating oil stain (we used 'Natural')
- Resene Roof Wash and Paint Cleaner (if applicable)
- Resene Lumbersider 'Gable Green' (for back of seat)
- Waterblaster
- Spray bottle
- Scrubbing brush
- Sandpaper & wire brush
- Paint brushes



1 OVER time, unstained decks can develop mould and unsightly black stains. Stains often result when plant pots are used without their saucers.



2 IF mould is present, spray the surface of your deck with Resene Moss & Mould Killer. Allow 48 hours to achieve full kill.



3 SCRUB vigorously with water to remove dead mould residues. For stubborn stains, scrub with Resene Roof Wash and Paint Cleaner.



4 WATERBLAST the entire deck until clean, then leave to dry. Note that deep stains caused by water may not disappear entirely.



5 STAIN the timber using Resene Woodsman penetrating oil stain in 'Natural'. Allow 24 hours to dry, then apply a second coat.



6 MEANWHILE, sand your bench seat back to its natural surface. Use a wire brush to remove dirt and debris on metal legs and seat back.



7 BRUSH away the dust, then stain wood with Resene Woodsman penetrating oil stain. We've used the same colour as the decking.



8 Paint the metal parts with Resene Lumbersider 'Green Gable'. For more on paints phone 0800 RESENE or visit www.resene.co.nz