Resene

Textured gilt frame

 $\star \star \star$ Difficulty level \star easy $\star \star$ moderate $\star \star \star$ challenging

Resene art with Mark Rayner – 72

You will need:

- Clean cloth
- Paintbrush
- Paint stirrer
- Resene Aquaclear gloss
- Resene Quick Dry

- Resene Sandtex
- Resene testpots of Resene Bullion and Resene Porsche
- Sandpaper
- Wooden picture frame



Step one Lightly sand the wooden frame.




Step two Wipe off any sanding residue with a clean cloth.



Step three Apply one coat of Resene Quick Dry to the wooden frame and allow to dry for two hours.



Step four Carefully stir the Resene Sandtex.





To get the look: Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Quarter Cararra.



Dear The second se

Step five Apply one generous coat of Resene Sandtex to the front and side edges of the frame, dabbing the paint to create a textured look. Allow to dry.



Step six Apply one coat of Resene Porsche to the front and side edges of the frame and allow two hours to dry.



Step seven Apply two coats of Resene Bullion to the front and side edges of the frame, allowing two hours for each coat to dry.





Step eight Apply three coats of Resene Aquaclear to the front and side edges of the frame. Allow two hours for each coat to dry.

Other ideas:

For a fresh retro look paint the frame with one coat of Resene Sandtex followed by two coats of Resene Gin Fizz.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out our special Artists' section online www.resene.com/artists.



In Australia: Call 1800 738 383, visit www.resene.com.au or email advice@resene.com.au In New Zealand: Call 0800 RESENE (737 363), visit www.resene.co.nz or email advice@resene.co.nz