Resene

Wooden bookcase



→ Difficulty level ★easy ★★moderate ★★★challenging

Fun with furniture with Mark Rayner - 29

You will need:

- Bucket of warm soapy water
- Clean cloths
- Clean water
- Old paintbrush
- Paintbrush
- Paint scraper
- Paint stirrer
- Resene Danska Teak Oil

- Resene Mineral Turpentine
- Resene Paint Pot
- Resene Strip-Off paint stripper
- Rubber gloves
- Sandpaper
- Sponge
- Wooden bookcase



Step one

Using an old paintbrush, carefully apply one generous coat of Resene Strip-Off paint stripper to the bookcase, working one area at a time. Allow the paint stripper to penetrate the old varnish.



Step two

When varnish has bubbled and softened, carefully scrape off with a paint scraper, running in the direction of the grain. Repeat if necessary until all varnish has been removed.



Step three

Wash off any residue with warm soapy water and rinse thoroughly with clean water. Allow to dry.



Step four

Sand the bare wood with a medium grade sandpaper, followed by fine grade sandpaper.



Step five

Wipe off any sanding residue with a clean cloth.



Step six

Carefully stir the Resene Danska Teak Oil.



Step seven

Apply one coat of Resene Danska Teak Oil to the bookcase brushing in the direction of the grain. Allow to penetrate the wood and then wipe off any excess with a clean dry cloth. Allow to dry for 24 hours.



Step eight

Wash brush thoroughly in Resene Mineral Turpentine.





To get the look:

Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Soft Apple.



Other ideas:

For a paler effect on bare or previously varnished wood use Resene Colorwood Whitewash.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/ artists_canvas.htm or

www.resene.com.au/ artists/artists_canvas.htm.



