



Difficulty level ★easy ★★moderate ★★★challenging

You will need:

- 18mm treated plywood cut to the following dimensions:
 - 2 x 400mm x 250mm (sides)
 - 2 x 300mm x 100mm (upper and lower back sections)
 - 300 x 198mm (back flap)
 - 300mm x 350mm (front)
 - 300mm x 320mm (top)
- 250mm x 264mm (base)
- 40mm galvanised nails
- Clean lint-free cloth
- Hammer
- Paintbrush
- PVA glue
- Resene Woodsman penetrating oil stain tinted to Resene English Walnut
- Sandpaper

Ways with wood,
with Mark Rayner – 18

Exterior

This simple plywood mailbox can be made in a matter of hours.



Step one
Cut the plywood to the dimensions as listed above and sand any rough edges with the sandpaper.



Step two
Fix the front and base to the side panels, as shown, using 40mm nails and PVA glue.



Step three
Fix the two back sections to the side panels, as shown, using 40mm nails and PVA glue.



Step four
Apply one coat of Resene Woodsman to the inside of the mailbox, brushing in the direction of the grain.



To get the look:
Mark painted the background wall with Resene Lumbardsider tinted to Resene Parachute.



Step five
Carefully wipe off any excess Woodsman oil stain with a clean, lint-free cloth.



Step six
Apply one coat of Resene Woodsman to the outside of the mailbox, the top and back flap. Brush in the direction of the grain and wipe off any excess with the cloth. Leave to dry for 24 hours.



Step seven
Repeat steps three and four, and when the inside is touch dry, fix the top into position with 40mm nails and PVA glue. Apply a second coat of Resene Woodsman to the outside of the mailbox and back flap. Wipe off any excess with the cloth and leave to dry for 24 hours.



Step eight
Fix the back flap into position with the two hinges and stainless steel screws, as shown.



Other ideas:

For a darker look, go for Resene Woodsman tinted to Resene Pitch Black.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.