

Upright planter

Difficulty level ★easy ★★moderate ★★★ challenging

Ways with wood with Mark Rayner – 41

You will need:

- 1.2m treated fence palings (x2)
- 50mm galvanised nails
- Drill with hole-cutting attachment
- Hammer

- Paintbrush
- Paint stirrer

- Pencil
- PVA glue (exterior)
- Resene Waterborne
 Woodsman penetrating
 oil stain tinted to
 Resene Earthsong

weight the the the transfer of the transfer of

- Sandpaper
- Saw
- Set square
- Tape measure



Step one

Measure halfway along each of the fence palings and mark a line using a pencil and set square.



Step two

Cut the fence palings in half using the pencil lines as a guide.



Step three

Measure, mark and cut three evenly spaced holes in two of the pieces of fence paling, as shown.



Step four

Fix these two pieces together, as shown, using PVA glue and nails.



Sten five

Attach the two remaining pieces of fence paling, as shown, fixing with PVA glue and nails.



Step six

Smooth any rough edges with sandpaper.



Step seven

Stir the Resene Waterborne Woodsman thoroughly with a paint stirrer.



Step eight

Apply two coats of Resene Earthsong to the planter, allowing two hours for each coat to dry.



Go vertical with this simple wooden planter and finish it off with a rich green from the Resene Woodsman exterior wood stains range.



To get the look:

Mark painted the background panel with Resene Lumbersider tinted to Resene Norwester and Resene Prussian Blue.



Other ideas:

For a rich red effect stain the planter with Resene Waterborne Woodsman tinted to Resene Totem Pole.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.