Resene

Modern mailbox

Difficulty level *easy ******moderate *******challenging

Ways with wood with Mark Rayner – 48

- You will need:
- Clean cloth
- Exterior PVA glue
- Jigsaw
- Paintbrushes (including an
 - artists' brush)
- Paint stirrerPencil
- Piece of treated
- plywood
 Plywood mailbox (ours came from Mitre 10 Mega)
- Resene Waterborne Woodsman testpot of Resene Heartwood
- Resene Waterborne Woodsman wood stain
- tinted to Resene Uluru • Sandpaper
- Sandpaper

The process of the state of the



Step one Draw the mailbox number on the piece of plywood with a pencil, as shown.



Step two Carefully cut out the number with a jigsaw.



Step three Smooth any rough edges with sandpaper and wipe off any sanding dust with a clean cloth.



Step fourApply two coats ofResene Heartwood tothe plywood numberallowing two hours foreach coat to dry.



Step five Lightly sand any rough edges on the mailbox and wipe off any sanding dust with a clean cloth.



Step six Stir the Resene Waterborne woodsman thoroughly with a paint stirrer.



Step seven Apply two coats of Resene Uluru to the mailbox, allowing two hours for each coat to dry.



Step eight Fix the number to the front of the mailbox with exterior PVA glue and allow glue to dry.

Exterior

Transform a simple plywood mailbox into something much smarter with wood stain colours from the Resene Woodsman range.



To get the look:

Mark painted the fence with Resene Lumbersider tinted to Resene Green Pea.



Other ideas:

For a cool blue effect try a combination of Resene Pickled Bluewood and Resene Woody Bay.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.



In New Zealand: Call 0800 RESENE (737 363), visit www.resene.co.nz or email advice@resene.co.nz