

Candleholder

Difficulty level ★easy ★★moderate ★★★challenging

The second secon

Ways with wood with Mark Rayner – 53

You will need:

- Clean cloth
- Paintbrush
- Paint stirrer
- Piece of dressed timber measuring approx 90mm x 90mm x 40mm (ours came from a renovator's centre)
- PVA glue
- Resene Aquaclear gloss
- Resene Colorwood Enhance Black
- Sandpaper
- Saw

CONTRACTOR OF THE PROPERTY OF

Wooden table leg



Step one

Cut the timber to size and trim the table leg to a 300mm length.



Step two

Smooth any rough edges with sandpaper and wipe off any sanding dust with a clean cloth.



Step three

Lightly sand the table leg and wipe off any sanding dust with a clean cloth.



Step four

Fix the table leg to the centre of the block of timber, as shown, using PVA glue. Allow glue to dry.



Step five

Shake the Resene Colorwood Enhance.



Step six

Carefully pour the Resene Colorwood Enhance into the Resene Aquaclear and stir thoroughly.



Step seven

Apply one coat of the coloured Resene Aquaclear to the candleholder and allow two hours to dry.



Step eight

Apply a second coat of the coloured Resene Aquaclear to the candleholder and allow two hours to dry.



Create this stylish candleholder from an old table leg and a block of timber and finish it off with easy-to-use Resene Colorwood Enhance and Resene Aquaclear.



To get the look:

Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Vitra.



Other ideas:

For a lighter brown finish use Resene Colorwood Enhance - Walnut.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.



