

Waste paper bin



★★ Difficulty level ★easy ★★moderate ★★★challenging

Ways with wood with Mark Rayner – 58

You will need:

- 37 pieces of 25mm x 25mm x 300mm pine – we used pine kindling (available from most supermarkets)
- 40mm panel pins
- Damp cloth
- Hammer

The second secon

- Heavy books
- Paintbrush
- Paint stirrer
- Piece of flat board
- PVA glue
- Resene Aquaclear gloss
- Sandpaper



Step one

Sand any rough edges from the pieces of pine and wipe off any sanding dust with a damp cloth.



CONTRACTOR OF THE PROPERTY OF

Step two

Form a square base with fifteen of the pine pieces, as shown, fixing with PVA glue and 40mm panel pins. Allow glue to dry and turn base the right way up.



Step three

Place two pieces of pine across opposite ends of the base, as shown, fixing with PVA glue and panel pins nailed from underneath.



Step four

'Stack' alternating pieces of pine along each edge, as shown, fixing at each corner with PVA glue.



Step five

Continue to build up the sides of the waste paper bin, as shown, fixing at each corner with PVA glue.



Step six

Place the board and books on top of the waste paper bin and leave overnight for glue to dry thoroughly.



Step seven

Carefully stir the Resene Aquaclear.



Step eight

Apply three coats of Resene Aquaclear gloss to the waste paper bin allowing two hours for each coat to dry.



Create this fabulous wooden waste paper bin from pieces of pine and finish off with Resene Aquaclear.



To get the look:

Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Colonial White.



Other ideas:

To create an attractive bleached wood effect, stain the pine with one coat of Resene Colorwood Rock Salt and allow to dry before applying the Resene Aquaclear.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.

