Resene

Boardwalk and raised bed



Exterior

Avoid muddy ground by

creating a simple

boardwalk between

two raised beds.

To get the look: Mark filled the raised bed with good quality topsoil and compost.



→ Difficulty level ★easy ★★moderate ★★★challenging

Ways with wood with Mark Rayner - 90

You will need:

- 50mm x 75mm treated timber (approximately 5m)
- 100mm exterior screws
- 1.5m fence palings (x6)
- **Decking nails**
- Drill with 3mm drill bit
- Hammer
- **Paint stirrer**
- Pencil
- **Paintbrush**

- Existing tongue and groove raised beds (treated with **Resene Moss & Mould Killer** and thoroughly cleaned using Resene Timber and Deck Wash)
- Resene Kwila Timber Stain
- **Resene Waterborne** Woodsman tinted to Resene **Grey Green**
- Saw

- · Scissors for cutting weed mat
- Screwdriver
- Spirit level
- Tape measure
- Turps for washing brush
- Tongue and groove landscaping timber (approx 8m)
- Weed mat and weed mat staples



Step one

Measure the lengths of the two existing raised beds and cut the 50mm x 75mm timber to fit. Fix these lengths to either side of the raised beds using 100mm screws, drilling pilot holes first. Use a spirit level to ensure the finished boardwalk will be level in both directions.



Step two

Lay the weed mat over the ground between the two raised beds and fix it down with weed mat pins.



Step three

Measure, mark and cut the tongue and groove landscaping timber to fit a second layer on the main raised bed. Fix these pieces together at each corner with 100mm screws, drilling holes first.



Step four

Measure, mark and cut the fence palings into sections to fit between the raised beds, as shown. Fix at each end with decking nails.



Step five

Carefully stir the Resene Waterborne Woodsman tinted to Resene Grey Green.



Step six

Apply two coats of Resene Waterborne Woodsman tinted to Resene Grey Green to the raised beds allowing two hours for each coat to dry.



Step seven

Carefully stir the Resene Kwila Timber Stain.



Step eight

Apply two coats of Resene Kwila Timber Stain to the boardwalk allowing 24 hours for each coat to dry. Wash brush with mineral turps.



For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Other ideas:

Pitch Black.

Check out more project ideas online www.resene.com/projects.

