

★★★ Difficulty level ★ easy ★★ moderate ★★★ challenging

Weekend DIY with Mark Rayner – 4

### You will need:

- 19mm plywood cut to the following dimensions: 330mm x 150mm (x2) 478mm x 150mm (x2)
- 7mm plywood cut to 475mm x 365mm
- Clean, lint-free cloth
- Construction glue
- Flat wooden paint stirrer
- Hammer
- Paintbrush
- Panel pins (25mm and 40mm)
- PVA glue
- Resene Aquaclear gloss
- Resene Waterborne Colorwood tinted to Resene Mahogany
- Resene Enamacryl Metallic tinted to Resene Silver Aluminium
- Resene Lumbersider tinted to Resene Silver Chalice
- Resene Waterborne Smooth Surface Sealer
- Sandpaper
- Twelve empty 1 litre Resene paint tins



#### Step one

Assemble the pieces of plywood to form a box, as shown. Use PVA glue and 40mm panel pins to fix the sides and 25mm panel pins to fix the back. Smooth any rough edges with sandpaper.



#### Step two

Carefully stir the Resene Waterborne Colorwood using a flat wooden stirrer and apply one coat to the plywood box. Leave to soak into the plywood for up to 15 minutes and then wipe off any excess with a clean, lint-free cloth. Allow to dry and then apply a second coat of Resene Mahogany to the box. Leave to dry for 48 hours.



#### Step three

Apply two coats of Resene Aquaclear gloss to the box, allowing two hours for each coat to dry.



#### Step four

Remove as much old paint as possible from the Resene paint tins and lightly sand any bare metal to provide a 'key'. Apply one coat of Resene Waterborne Smooth Surface Sealer to the inside and outside of each tin. Allow two hours to dry.



#### Step five

Apply one coat of Resene Silver Chalice to the inside and outside of each tin and allow two hours to dry.



#### Step six

Apply two coats of Resene Silver Aluminium to the inside and outside of each tin, allowing two hours for each coat to dry.



#### Step seven

Apply two coats of Resene Aquaclear gloss to the inside and outside of each tin, allowing two hours for each coat to dry.



#### Step eight

Place the tins in the plywood box, as shown, fixing each base with a generous blob of construction glue. Allow glue to dry before standing the right way up and sliding a wine bottle into each tin.

Go green and recycle your old Resene paint tins into this fabulous wine rack.



### To get the look:

Mark painted the background wall colour with Resene SpaceCote Low Sheen tinted to Resene Wild Thing.



### Other ideas:

Create a warm luxurious copper finish by using a basecoat of Resene El Salva with a topcoat of Resene Copper Fire.

For more ideas and inspiration visit your local Resene ColorShop or [www.resene.co.nz](http://www.resene.co.nz) or [www.resene.com.au](http://www.resene.com.au).

Check out our special Artists section online [www.resene.co.nz/artists/artists\\_canvas.htm](http://www.resene.co.nz/artists/artists_canvas.htm) or [www.resene.com.au/artists/artists\\_canvas.htm](http://www.resene.com.au/artists/artists_canvas.htm).