

You will need:

- Clean cloth
- Old wooden window (thoroughly cleaned and treated with Resene Moss & Mould Killer if necessary)
- Paintbrushes
- Resene Lustacryl tinted to Resene Dragon
- Resene Quick Dry
- Resene Timber Surface Prep
- Sandpaper
- Scraper



Step one

Scrape off any loose and flaking paint from the window surround and frame.



Step two

Sand smooth to 'feather' the edges where the existing paint meets bare wood.



Step three

Sand the rest of the window frame and sill to 'key' the surface. Wipe off any sanding residue with a clean cloth.



Step four

Apply one coat of Resene Timber Surface Prep to the window surround and frame and allow to dry.



Step five

Sand the Resene Timber Surface Prep to a smooth finish and wipe off any sanding residue with a clean cloth. Repeat steps four and five if necessary.



Step six

Apply one coat of Resene Quick Dry over the Resene Timber Surface Prep and spot prime any areas of bare wood on the window sill. Allow to dry.



Step seven

Apply one coat of Resene Lustacryl tinted to Resene Dragon to the window frame, surround and sill. Allow to dry.



Step eight

Apply a second coat of Resene Lustacryl tinted to Resene Dragon to the window frame, surround and sill. Allow to dry.

When timber surfaces are less than perfect, Resene Timber Surface Prep will help to solve the problem.



To get the look:

Mark painted the surrounding weatherboards with Resene Lumbersider tinted to Resene Rockbottom.



Other ideas:

For a fresh white look, paint the window frame with Resene Lustacryl tinted to Resene Half Alabaster.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/colorshops.

Check out more project ideas online www.resene.com/projects.