Resene product labels are updated from time to time. This label is provided as a guide for this product and may differ from the label on the container you purchase. Please discuss your project with your local Resene ColorShop team or reseller to ensure you have the right products to give you the best quality finish for your specific project.

How to use

Step 1: Add 100ml of Cloudy Ammonia and stir aggressively.

Step 2: Add 100ml of Resene WashWise Flocculent and stir aggressively.

Step 3: Check for separation. This should be visible after 30 minutes. Add an extra 50ml of Resene WashWise Flocculent and stir if no change noticed.

Step 4: Leave overnight.

Step 5: Attach the waste pipe to the outlet tap and direct the other end to sewerage, a flat surface or lawn away from stormwater drains or natural water sources, or to a waste container.

Step 6: Open the tap and run off the clear/thin coloured waste water. This is a mixture of water, colourants, and other liquid parts of paint. Do not release to stormwater systems.

Step 7: Remove the paint sludge. This can be mixed with a small scoop of Resene Washwise Crystals to make it solid or left to dry, then disposed of through your normal rubbish service.

