

Copper concealment

Hide a drab wall with this funky trellising for plants to climb up.

You will need:

- Resene Concrete Primer
- Resene Quick Dry Acrylic Primer Undercoat
- Resene Lumbersider in Resene Pale Prim and Resene Black Forest
- Resene Sandtex in Resene El Salva
- Resene Enamacryl in Resene Copper Fire
- Resene Multishield+ Gloss
- Resene Paint Prep and Housewash
- 1.8m x 1.8m trellis panel
- 7.2m fence capping
- 75mm brass screws
- Paint brush
- Paint tray/roller
- Mitre box
- Handsaw, skilsaw
- Drill
- Screwdriver



phone o8oo RESENE or visit www.resene.co.nz



To get the look We planted hardenbergia either side of the trellis panel. Ceramic Water Work by Rick Rudd (www.rickrudd.com).



WASH garage walls with Resene Paint Prep and Housewash and paint with one coat of Resene Concrete Primer. Allow to dry. The fibrolite walls of this garage are quite new. For older concrete surfaces, contact Resene for advice.



PAINT the trellis panel and fence capping with one coat of Resene Quick Dry Acrylic Primer Undercoat. Allow to dry.



PAINT the trellis and fence capping with two coats of Resene Black Forest, allowing two hours to dry between



PAINT the garage walls with two coats of Resene Pale Prim, leaving a 1.75m square where the trellis will be attached.



USING the mitre box, handsaw and set square, create a 1.8m square frame from the fence capping, as shown. Secure at each corner with brass



USING a large brush and "stippling" technique, apply a generous coat of Resene Sandtex in Resene El Salva, covering the 1.75m square. Allow to



USING a paint roller, apply two coats of Resene Enamacryl in Resene Copper Fire to the 1.75m square. Allow to dry and finish off with one coat of Resene Multishield+ Gloss.



USING a drill, screwdriver and copper screws, attach the 1.8m square capping frame to the garage wall, and screw the trellis panel to the square capping frame.