



YOU WILL NEED:

- Old wooden louvre-style cupboard door
- Piece of recycled wood for shelf (approx. 20mm thick)
- Three small 'long tom' terracotta pots
- · Exterior wood filler
- Putty knife or similar for filling
- Sandpaper
- Clean cloth
- Two decorative metal shelf brackets (ours came from Mitre 10 Mega)
- 20mm stainless-steel screws
- Screwdriver
- PVA glue
- Paintbrush
- Resene Ouick Dry
- Resene Terracotta Sealer
- Resene
 Lustacryl tinted to Resene
 Tranquil
- Resene testpot of Resene Alabaster



STEP ONE

Measure, mark and cut the piece of wood for the shelf so it's approximately 100mm wider than the cupboard door. Sand any rough edges.

STEP TWO

Fill any holes in the cupboard door with exterior filler, allow to dry, and then sand smooth. Lightly sand the cupboard door to remove any loose varnish.

STEP THREE

Wipe off any sanding residue with a clean cloth.

STEP FOUR

Run a line of PVA glue along the back edge of the shelf and then fix into position on the cupboard door, as shown. Attach the brackets using 20mm screws. Wipe off any excess glue and allow to dry.

STEP FIVE

Apply one coat of Resene Quick Dry to the entire unit and allow two hours to dry.

STEP SIX

Apply two coats of Resene Tranquil to the entire unit, allowing two hours for each coat to dry.

STEP SEVEN

Apply one coat of Resene Terracotta Sealer to the inside and outside of each terracotta pot and allow to dry.

STEP EIGHT

Apply two coats of Resene Alabaster to each terracotta pot, allowing two hours for each coat to dry.



