

Screen Play



Whether constructing a new fence or putting in a screen, corrugated iron is the perfect choice for a contemporary look.

You will need:

- Timber fence capping
- Sheets of corrugated iron
- Resene Galvo-Prime
- Resene Lumbersider tinted to Resene Ebony Clay
- Resene Waterborne Woodsman penetrating stain in Resene Nutmeg
- Saw
- Drill
- Hammer
- Galvanised nails and screws
- Paint brushes
- Fence fastenings

For more on paints phone 0800 RESENE or visit www.resene.co.nz



1 TO provide shelter from high winds and privacy from neighbours, a framed corrugated iron screen is just the thing.



2 TO make the frames, measure the iron sheets then cut four corresponding lengths of fence capping for each panel (2 sides, 1 top and 1 bottom), cutting ends at a 45° angle.



3 PAINT the fence capping with Resene Waterborne Woodsman penetrating stain before assembling. Allow 24 hours to dry before applying a second coat. Allow another 24 hours to dry.



4 APPLY a coat of Resene Galvo-Prime to the iron panels. We've used new corrugated iron sheets. If using weathered sheets, prime with Resene Galvo One.



5 WHEN dry, apply two coats of Resene Lumbersider tinted to Resene Ebony Clay on both sides of the iron panels. Alternatively, use Resene Hi-Glo in Resene Ebony Clay for a glossy finish.



6 WHEN fence capping is dry, fix mitred corners with galvanised nails or screws. Leave one end of the frame open. Some adhesive on the mitred joints will make for a better connection.



7 SLIDE the iron panels into the three-sided frames, then fix the remaining sides to each frame.



8 FIX first panel in position, then fix remaining panels to one another with fence fastenings, one at the top and bottom of each panel.